



Installing your SaveStation Indoor Cabinet (SS150)

The SaveStation Alarm Cabinet should be mounted in a highly visible and accessible area. The goal is for everyone at the facility to know where the AED is located, and for the AED retrieval to be fast.

Signage

1. Mount the SaveStation 4' (48 inches) off the ground, measuring to the middle of the cabinet door. **If you have a modular cabinet, measure and install this first, ensuring the AED cabinet handle is no more than 48" from the ground.*
2. Install the 3D sign above the cabinet - approx 2' if space allows.
3. Place the SaveStation poster to the side or above the cabinet at a good reading height.
4. The ready symbol of the AED must be visible through the cabinet window.
5. Adhere the front door location sticker to all entrances or at least the major entrances to your facility.



Front Door Sticker

